

# EWD-H-J3

USER' S GUIDE

(V2.2

Xi'an Excellent Electromechanical Co.,Ltd.

---

Table of Contents	<b>Product Overview</b>	1、Product Appearance, inner structure and interface directions .....	Page 2
		2、Exterior dimensions and installing diagram .....	Page 3
	<b>Installation &amp; Adjustment</b>	3、System Adjustment and directions .....	Page 4
	<b>Implication and Adjustment Method of the Operation Parameters</b>	4、System Parameters Adjustment .....	Page 6
		5、Explanation of the Meaning of Parameter P .....	Page 7
	<b>Indicating Code Explanation</b>	6、Explanation of System Normal Operation Code .....	Page 9
		7、Explanation of other displaying .....	Page 9
	<b>How To Do?</b>	8、Brief introductions of conditions .....	Page 10
		9、How to do setting adjustment of an elevator with the known “no load rated load” compressing deformation? .....	Page 10
		10、How to repeat the Autotune operation for the system? .....	Page 11
		11、How to modify the system output conditions after Autotune? .....	Page 11
		12、How to use 20% rated load autotune? .....	Page 11
		13、Car shock rubber compression exceeds the sensor detection range .....	Page 11
		14、On the use of "load increase, away from" working methods of operation .....	Page 11
		15、Working principle of “EWD-H-J3” elevator weighing device .....	Page 11
	<b>System Characteristics</b>	16、Main Properties .....	Page 12
		17、Technical Items .....	Page 12
	<b>Promise</b>	.....	Page 13
	<b>Others</b>	.....	Page 14



**Caution:** This system is applicable an elevator with 「moveable car platform」.Before use, please read the following content carefully.  
The Inductive magnet is specially-made rare-earth magnet for this product with strong magnetic force. Special care should be taken during installation. Under no condition should it be away from the high temperature above 100℃ to avoid demagnetizing and the equipment damage and personal hurt from this is beyond our responsibility.

**Notice:** Our part is just responsible for the products quality in the guarantee period under any condition.

**Declaration:** Our company reserves the right of changing products for technical improvement and the related technical parameters should be referred to the USER’ S GUIDE along with the products.

Product Overview

1、Product Appearance, Interior Structure and Interface Directions:


		EWD-H-J3	
Appearance			Interior Tructure
		 <p>system default J1: Light load J2: Full load J3: Over load</p> <p>Doors switch Relay</p> <p>Power supply AC/DC24V</p>	
Interface Directions	P1	Com	Common terminal “Com”: 2-channel solid-state relay output
	P2	J1	
	P3	J2	
	P4	J3. 1	Independent 1-channel solid-state relay output
	P5	J3. 2	
	P6	Cooperate with P7 to hold J1 ~ 3 status (Unused normally)	
	P7	①System Power Source: DC/AC24V(±10%) / 150mA ②Absolutely not to connect the output terminals of this device except “P7、P8” to exterior power source directly, and the permanent damage from this is beyond our responsibility.	
	P8		
1.J1~J3 are interior solid state relays with Max. loading capacity of DC/AC 32V/50mA. 2.To be programmed as “no load~over load” output signal to participate in elevator logic control.			

## 2、Exterior Dimensions & Installing Scheme

Exterior Dimension	<p>Fig [2]</p>	<h3>Notice on Installation</h3> <ol style="list-style-type: none"><li>1. Install this device as near as possible to the center of elevator car platform or the original place of elevator overload switch. The system should be installed on the bottom bearing beam of elevator car platform with the inductive magnet adhering to the moveable car platform and the marking surface facing to the inductive point of the weighing device.</li><li>2. The system supporting frame should be made according to elevator concrete situation with the uneasily deforming material of thickness more than 4mm or with enforcing plate to avoid swaying.</li><li>3. Adjust this device so that the car platform magnet aiming to the center point of its upper section. Meanwhile, assure that the section of this device parallel to that of the magnet.</li></ol>
Installing Method	<p>注意：系统连接支架需要用户根据具体情况自制</p> <p>图[3]</p>	


### 3、System Adjustment and Directions

#### ① System Positioning Operation:



② No load and Rated Load Operation Parameters for Autotuning:

When displaying [Lo], press【▲】and【▼】simultaneously, the system will start no-load operating parameters autotuning. When [PL] is displayed aglimer for 5s, it is the end of no-load autotuning.



③System Adjustment under other conditions:

For the following reason, it is necessary to modify the operating parameters of this device.

- ① For elevator car decoration change, the dead weight of the moveable car platform changes;
- ② The car platform appears mechanical deformation;
- ③ The temperature difference between winter and summer has an unneglecting effect on the elastic coefficient of car platform damping rubber;
- ④ The car platform appears damping rubber appears aging or deforming;
- ⑤ The elevator overruns at the top or at the bottom;
- ⑥ The weighing device becomes slack at the fixing end.

## Operation Parameters Adjustment and the Implication

---

### 4、System Operation Parameters Adjustment (Annotation: \* represents for a hexadecimal value of “0~9,A~F” )

- ① Simultaneously press 【▲】 and 【▼】 on system control keypad to power on , this moment 【PP】 will be displayed aglimer, that means entering operation parameters modifying status.
- ② Release 【▲】 and 【▼】 buttons, system will display 【P\*】 and 【\*\*】 alternately. 【P\*】 is an indication of system operation parameters; 【\*\*】 is the interior data value of 【P\*】 .
- ③ When displaying 【P\*】 , press 【▼】 , indication of system operation increases; press 【▲】 , indication decreases.
- ④ When displaying 【\*\*】 , press 【▼】 , data value increases; press 【▲】 , data value decreases.
- ⑤ Release buttons, system displays operation indication and configuring data alternately.
- ⑥ To modify other configuring datum, repeat the operation in item 3, item 4, item 5.
- ⑦ At the moment when system displays 【P\*】 , Simultaneously press 【▲】 and 【▼】 , system will save modified datum for future use. This moment, system displays【Pn】 for 1 second. System operation parameters modification of this time is completed.

#### **Example: Modify parameter P2 to 16;**

- ① Simultaneously press 【▲】 and 【▼】 on system control keypad to power on , this moment 【PP】 will be displayed aglimer, that means entering modifying status.
- ② Release 【▲】 and 【▼】 buttons, system will display 【P0】 and 【\*\*】 aglimer
- ③ When displaying 【P0】 , press 【▼】 to increasing it to 【P2】 ;
- ④ Release button 【▼】 , system alternately displays 【P2】 and 【\*\*】 ;

- ⑤ When displaying [\*\*], press [▲] or [▼] to regulate its value as [16];
- ⑥ Release button, system alternately displays [P2] and [16];
- ⑦ At the moment when system displays [P2], Simultaneously press [▲] and [▼], system will save modified datum for future use. This moment, system displays [Pn] for 1 second. System operation parameters modification is completed.

## 5、Implication of parameter P:

① Directions of Parameter P0 [System Operation Mode]:

Setting	Explanation	Default Setting	Normal Value
00	Normal Operation	01	00 This value will be modified in the course of autotuning.
01	Sensor installing positioning, system no-load and rated-load autotuning operation.		
02	Specifying system no-load autotuning operation.		
03	Specifying system Rated-load autotuning operation.		
04	Select “20% rated load” autotuning operation, being convenient for users special adjustment.		
25~99 ×0.1mm	For elevator with known “no-load→rated-load” compressing moveable car platform damping rubber pad, it may be set manually. The system may be put into use after system installation positioning. (This adjustment is very convenient for elevator manufacturers. For more detail, refer to Chapter 10.)		

② Directions of Parameter P1

[Hold input signal status setting and relay output condition setting]:

Setting	Explanation	Default Setting	User Setting
00	0-Stepped output 0-P6 and P7 are short circuited, system output signal will be held.	00 Stepped output, short circuit for holding	

③ Directions of Parameter P2 [Light-load parameter setting]:

Setting	Explanation	Default Setting	User Setting
00~30	Light load signal output	05	

④ Directions of Parameter P3 [Light-load parameter setting]:

Setting	Explanation	Default Setting	User Setting
---------	-------------	-----------------	--------------



# Technical File of the EWD-H-J3 Intelligent Elevator Load Weighing Device [User's Guide]

P2+1~60	Half-load signal output	30	
---------	-------------------------	----	--

## ⑤Directions of Parameter P4[Semi-load parameter setting]:

Setting	Explanation	Default Setting	User Setting
P3+1~90	Heavy-duty signal output	70	

## ⑥Directions of Parameter P5 [heavy-load parameter setting]:

Setting	Explanation	Default Setting	User Setting
P4+1~99	Full-load signal output	90	

## ⑦Directions of Parameter P6 [System overload coefficient]:

Setting	Explanation	Default Setting	User Setting
00~20	Load *105%, overload signal output	05	

## ⑧Directions of Parameter P7 [Operation Status setting of Solid state relay “J1” ]:

Setting	Explanation	Default Setting	User Setting
00~1F	Light-load action close out put	01(Light load action close)	

## ⑨Directions of ParameterP8 [Operation Status setting of Solid state relay “J2” ]:

Setting	Explanation	Default Setting	User Setting
00~1F	Full-load action close out put	04(Full load action close)	

## ⑩Directions of Parameter P9 [Operation Status setting of Solid state relay “J3” ]:

Setting	Explanation	Default Setting	User Setting
00~1F	Over-load action open output	1F(Over load action open)	

## ⑪Directions of Parameter D [Displacement-expanding Setting]:

Setting	Explanation		Default Setting	User Setting
01~03	Higher Bit	Lower Bit	01 displacement closing 10mm valid	
	0-Load increases, displacement approaches	1. Select sensor 0~9.9mm valid;		

**Notice:** ①Select unindicated setting will lead to system abnormal operation.

②Even if auto-zeroing function is in use, autotuning operation should be done again in the course of periodical maintenance.

## Explanation of Displaying Code:

### 6、System Normal Operation Code: ( “W” is the present effective load)

Display Code			Indication
System displays 【L*】	L0	No-load car	Output No-load signal
	L1	Light-load car	Output Light-load signal
	L2	Half-load car	Output Semi-load signal
	L3	Heavy-load car	Output Heavy-load signal
	L4	Full-load car	Output Rated-load signal
	LF	Over-load car	Output Over-load signal
For user to save: the code of this elevator			Rated-load Compression: mm

### 7、Code for Other Operation and Failures

	Display Code	Indication	Solution
1	FY	System Startup	
2	Pc	System Resetting	
3	PP	Get into the status of operation parameters modification	
4	PL	Autotuning No load parameters (Static Displaying represents preparative status, twinkling displaying for the end of testing)	
5	PH	Autotuning Rated load parameters (Static Displaying represents preparative status, twinkling displaying for the end of testing)	
6	LL	Installation and positioning	Too big Positioning
7	LH		Move this device closing to the magnet
8	Lo		Too small Positioning
9	LP		Move this device away from the magnet
10	P*	System Configuration Indication	
11	Pn	Saved	

	Display Code	Indication	Solution
12	EE	Variables at the bottom of the car overflow	Vibration damping rubber too soft, adjust the PD parameters

## How to do?

### 8、Brief Analysis of Other Conditions:

①After installation of this weighing device, weighing signal changes in the course of operation?

The elevator load output value is not held after elevator starts, adjust the relative items of the inverter and controller.

②After long-term of operation, system no load zeroing point appears larger deviation?

May be caused by the reason described in section 3,Chapter 3. Set system Autotuning mode to calibrate again

③After the elevator weighing is changed from heavy load to light load, heavy load signal is still displayed?

The movement of the moveable car platform is blocked, it is not reset after pressing. Solute the relevant mechanic problems.

④System output signal doesn' t change linearly along with the change of load?

Check the structure of the moveable car platform, pay more attention that there should only be one pair of damping rubber or spring moving relatively to the moveable car platform.

⑤During the system operation, analog output is abnormal or system resetting or speed-regulator cooperation is abnormal?

It may be caused by system power source series interference. Select another group of power to supply the system, or to provide an exterior power of AC/DC 24V/300mA to supply.

### 9、How to set an elevator with known “no-load→rated load” compression deformation?

For example: The max “no-load→rated load” compression deformation of this elevator is 5.8mm.

- |        |  |
|--------|--|
| Operat | <ol style="list-style-type: none"> <li>1.Modify “P0=58” and save it. Refer to chapter 5;</li> <li>2.After system restarting, [LP] is displayed. Wait until [LL] , [Lo] or [LH] is displayed;</li> <li>3.When the car is empty, adjust system installation position to make it display [Lo] , fasten it;</li> </ol> |
|--------|--|

4. When [Lo] is displayed, press [▲] and [▼] simultaneously, system begins to autotune no-load operation parameters;
5. After [PL] is displayed again for 5 seconds, the whole process of autotuning is finished.

## 10、How to do Re-Autotune operation for system?

**Method 1:** Simultaneously press [▲] and [▼] on system control panel to power on. This moment, system aglimer displays [PP] and [P-]. Keep 15 seconds, system will display [Pn]. On that occasion, all operation parameters reset to default settings.

**Method 2:** Modifying parameter P0=0A or user specified operation code will reset system immediately to default status. But for users with specified code. The method is mentioned in Chapter 5.

## 11、How to modify output status of a system after autotuning is finished?

Modify the corresponding controlling parameters of parameter P respectively. The method is mentioned in Chapter 4 and 5.

## 12、How to adopt 20% rated load for rated load autotune?

Modify P0=04. After [Lo] positioning and no-load [PL] autotuning, in the period of system displaying [PH], load 20% of the rated load, press [ ], system displaying [L1] means the end of adjustment. This is an auxiliary method when 100% autotuning can be done.

## 13、The compression of car damping rubber exceeds the sensor inspection range?

Before autotuning, be assured to select "PD"="02/03" and save it. Then, readjusting the installing position of the sensor is OK (See parameter PD for more details).

## 14、On adopting operation of "load increasing, displacement alooing" method?

Before autotuning, be assured to select "PD"="1\*" and save it. Then, readjusting the installing position of the sensor is OK.

## System Characteristics

---

## 15、Working principle of "EWD-H-J3" elevator weighing device

With the development of elevator technology, the influence of elevator weighing device on its performance has reached a point that cannot be ignored. High precision of elevator to weighing device, The demand of high reliability and multi-function is imminent. With the development of sensor technology and microcomputer, Hall sensors with high precision are used to detect The displacement of elevator car bottom due to the load is changed. At the same time, the single chip microcomputer is used to deal with it scientifically, so that the device can realize the change of elevator car Working function of effective load weighing.

### 16、Main property

- (1) Working in a contactless and inductive way. No mechanical movement. Solid-state relay outputs. Being directly installed in the original place of overloading switch. No necessity of changing the mechanism of elevator car.
- (2) The whole system is designed in the waterproof structure with small overall size, easy installation and adjustment and simple structure.
- (3) Wide induction range, high accuracy positioning, intelligent temperature compensation making the range of operating temperature wider.
- (4) The inner core consists of Hall sensor of high accuracy and single-chip microprocessor of high efficiency. All parameters may be set on the field.
- (5) Adopting strong inductive magnet, improving the anti-interference capability of the system to the utmost.
- (6) Each set of products undergo a rigorous aging process to ensure reliable work.
- (7) System based on mathematical equations for scientific computing, automatic detection error correction
- (8) On-site adjustment is easy, either by autotuning or by manual displacement setting.
- (9) The independent development of the programmable output signal control method can be used for all kinds of traction elevator with moveable car platform.

### 17、Technical specifications:

1.	Application	Being applicable to all moveable car platform elevators, with an auto inspection range of $(2.00\text{mm} \leq \text{car platform movement} \leq 10.00\text{mm})$ ; manual setting displacement
----	-------------	---

## Technical File of the EWD-H-J3 Intelligent Elevator Load Weighing Device [User's Guide] [V2.2]

		range 2.5~9.9mm (relate to parameter PD)	
2.	Sensitivity	Elevator rated load/200 (With the rated load of 1T, it is 5.0Kg)	
3.	System Error	$\leq 1.5\%$ (5~40℃)	In the whole temperature range $\leq 3.0\%$
4.	Non-Linearity	$\leq 1.0\%$	
5.	Output Mode:	Solid-state Relay Programmable universal signal	① 3/5 channel programmable output modes are: No load, light load, semi full load, heavy load, rated load, overload (customer may set the changing range freely). ② Each channel can be programmed as dynamic Close or Open contact. ③ Contact Capacity: DC/AC 32V/15mA。
6	Working Temperature:	-20~55℃	
7	Relative Humidity:	20%~99%RH	
8	Reaction Time	$\leq 0.25$ Second	
9	Power Supply:	AC/DC 24( $\pm 10\%$ )V / 150mA	
10	Installation Place:	Moveable car platform of elevator	
11	Overall Size:	45×45×90 mm <sup>3</sup>	

✱: The intension exceeding the limit parameters listed above may result in the abnormality or permanent damage to the system.

### Promise

- (1) If this system appears any quality problem of product itself in 1 year after delivery, it will be replaced freely (damage of the product seal will not be dealt with)。
- (2) For any requirement of special functions, make it out by mail.





(3)Any system abnormality in adjustment or operation, please contact our company directly.

Others

---

1 .Accessory	Instruction Manual	1 copy	Fixing Screw set	2 sets
	Inductive magnet [20×20×4mm3]	1 piece		

2.address book:

	029-88416613	85565714		7D, Block A, Olympic Building, 14th
	029-85568478			Chang An North Road, Xi'an
	029-85565714-886			710068
Technical support:18092639752 18092639750				