

# EWD-H-SJ3

## USER' S GUIDE (V2.2)

Xi'an Excellent Electromechanical Co., Ltd.

---

# EWD-H-SJ3 User manual for technical documents of intelligent elevator weighing device[V2.2]

Table of Contents	<b>Product Overview</b>	1、Product Appearance, inner structure and interface directions	Page 2
		2、Exterior dimensions and installing diagram	Page 4
	<b>Installation &amp; Adjustment</b>	3、System Adjustment and directions	Page 5
	<b>Implication and Adjustment</b>	4、System Parameters Adjustment	Page 7
	<b>Method of the Operation</b>	5、Explanation of the Meaning of Parameter P	Page 9
	<b>Parameters</b>		
	<b>Indicating Code</b>	6、Explanation of System Normal Operation Code	Page 10
		7、Explanation of other displaying	Page 10
	<b>How To Do?</b>	8、Brief introductions of conditions	Page 11
		9、How to do setting adjustment of an elevator with the known “no	Page 11
		10、How to repeat the Autotune operation for the system?	Page 12
		11、How to modify the system output conditions after Autotune?	Page 12
		12、How to use 20% rated load autotune?	Page 12
		13、Car shock rubber compression exceeds the sensor detection range	Page 12
		14、On the use of "load increase, away from" working methods of	Page 12
		15、Working principle of “EWD-H-SJ3” elevator weighing device	Page 12
	<b>System Characteristics</b>	16、Main Properties	Page 13
		17、Technical Items	Page 13
	<b>Promise</b>		Page 15
	<b>Others</b>		Page 15



**Caution:** This system is applicable an elevator with 「moveable car platform」. Before use, please read the following content carefully. The Inductive magnet is specially-made rare-earth magnet for this product with strong magnetic force. Special care should be taken during installation. Under no condition should it be away from the high temperature above 100℃ to avoid demagnetizing and the equipment damage and personal hurt from this is beyond our responsibility.

**Notice:** Our part is just responsible for the products quality in the guarantee period under any condition.



**Declaration:** Our company reserves the right of changing products for technical improvement and the related technical parameters should be referred to the USER’ S GUIDE along with the products.

Product Overview

1、Product Appearance, Interior Structure and Interface Directions:


		EWD-H-J5	
Appearance			<div>Interior Structure</div>  <p>system default P1-P2: J1No load P1-P3: J2Full load P1-P4: J3Overload P5-P6: 0-10V</p> <p>Power supply AC/DC24V</p>
Interface Directions	P1	Com	Common terminal J1,J2,J3, is 3 channel Solid State Relay Output
	P2	J1	
	P3	J2	
	P4	J3	
	P5	Analog 0-10v	
	P6		
	P7	System Power Source: DC/AC24V( $\pm 10\%$ ) / 150mA	
	P8	Absolutely not to connect the output terminals of this device except “P7、P8” to exterior power source directly, and the permanent damage from this is beyond our responsibility.	
		1.J1~J3 are interior solid state relays with Max. loading capacity of DC/AC 32V/50mA. 2.To be programmed as “no load~over load” output signal to participate in elevator logic control.	

2、Exterior Dimensions & Installing Scheme

Exterior Dimension	<div></div>	<div><p><b>Notice on Installation</b></p><p>1.Install this device as near as possible to the center of elevator car platform or the original place of elevator overload switch. The system should be installed on the bottom bearing beam of elevator car platform with the inductive magnet adhering to the moveable car platform and the marking surface facing to the inductive point of the weighing device.</p><p>2.The system supporting frame should be made according to elevator concrete situation with the uneasily deforming material of thickness more than 4mm or with enforcing plate to avoid swaying.</p><p>3.Adjust this device so that the car platform magnet aiming to the center point of its upper section. Meanwhile, assure that the section of this device parallel to that of the magnet.</p></div>
Installing Method	<div></div>	

### 3、System Adjustment and Directions

#### ①System Positioning Operation:



② No load and Rated Load Operation Parameters for Autotuning:

When displaying [Lo], press [▲] and [▼] simultaneously, the system will start no-load operating parameters autotuning. When [PL] is displayed twinkle for 5s, it is the end of no-load autotuning.

yes

The weighing device will automatically enter a self - learning load work - ready state, showing [PH]. Enter the load self - learning ready state.

yes

1. Display [PH] when placing the elevator in load state (example: load 1000kg elevator, load 1000kg);
2. Press [▼] system to start self-learning load working parameters. Flashing display - 4 seconds, weighing memory load data.

yes

Displaying [L4] means the end of RL operating parameters autotuning

yes

By the way of setting

Displaying [L0], Self - learning load working parameters completed

yes

By now, system debugging is finished. System will enter normal operation condition. For the meaning of displaying code, please refer to Chapter 6

① System Adjustment under other conditions:

For the following reason, it is necessary to modify the operating parameters of this device.

- ①For elevator car decoration change, the dead weight of the moveable car platform changes;
- ②The car platform appears mechanical deformation;
- ③The temperature difference between winter and summer has an unneglecting effect on the elastic coefficient of car platform damping rubber;
- ④The car platform appears damping rubber appears aging or deforming;
- ⑤The elevator overruns at the top or at the bottom;
- ⑥The weighing device becomes slack at the fixing end.

## Operation Parameters Adjustment and the Implication

---

### **4、System Operation Parameters Adjustment** (Annotation: \* represents for a hexadecimal value of “0~9,A~F” )

①Simultaneously press **【▲】** and **【▼】** on system control keypad to power on , this moment **〔PP〕** will be displayed aglimer, that means entering operation parameters modifying status.

②Release **【▲】** and **【▼】** buttons, system will display **〔P\*〕** and **〔\*\*〕** alternately. **〔P\*〕** is an indication of system operation parameters; **〔\*\*〕** is the interior data value of **〔P\*〕** .

③When displaying **〔P\*〕** , press **【▼】** , indication of system operation increases; press **【▲】** , indication decreases.

④When displaying **〔\*\*〕** , press **【▼】** , data value increases; press **【▲】** , data value decreases.

⑤Release buttons, system displays operation indication and configuring data alternately.

⑥To modify other configuring datum, repeat the operation in item 3, item 4, item 5.

⑦At the moment when system displays **〔P\*〕**, Simultaneously press **【▲】**and**【▼】**, system will save modified datum for future use. This moment, system displays**〔Pn〕** for 1 second. System operation parameters modification of this time is completed.

**Example: Modify parameter P2 to 16;**

- ① Simultaneously press **【▲】** and **【▼】** on system control keypad to power on , this moment **〔PP〕** will be displayed twinkle alternatively, that means entering modifying status.
- ② Release **【▲】** and **【▼】** buttons, the weighing device will alternately show **[P0]** and **[\*\*]**;
- ③ When displaying **〔P0〕** , press **【▼】** to increasing it to **〔P2〕** ;
- ④ Release button **【▼】** , system alternately displays **〔P2〕** and **〔\*\*〕** ;
- ⑤ When displaying **〔\*\*〕** , press **【▲】** and **【▼】** to regulate its value as **〔16〕** ;
- ⑥ Release button, system alternately displays **〔P2〕** and **〔16〕** ;
- ⑦ At the moment when system displays **〔P2〕**, Simultaneously press **【▲】** and **【▼】**, system will save modified datum for future use. This moment, system displays **〔Pn〕** for 1 second. System operation parameters modification is completed.

**5、Implication of parameter P:**

① Directions of Parameter P0 [System Operation Mode]: :

Setting	Explanation	Default Setting	Normal Value
00	Normal Operation	01	00
01	Sensor installation positioning, weighing device self-learning "empty and rated load" mode		This value is automatically corrected in the self-learning process of the
02	Specified weighing device self-learning "empty-load" mode of operation		
03	Specified weighing device self-learning "rated-load" mode of operation		
04	Select "20% load" self-learning, working mode, convenient users special debugging mode		



## EWD-H-SJ3 User manual for technical documents of intelligent elevator weighing device[V2.2]

25~99 × 0.1mm	For elevator with known “no-load → rated-load” compressing moveable car platform damping rubber pad, it may be set manually. The system may be put into use after system installation positioning. (This adjustment is very convenient for elevator manufacturers. For more detail, refer to Chapter 0.)		weighing device
---------------------	--	--	-----------------

### ②Directions of Parameter P1

Setting	Explanation		Default Setting	User Setting
00、01 10、11	Higher bit 0-Cascade output mode	Lower bit 0.-P5 and P6 ports are “10-0V” Analog output	00 Cascade output,0~10V,P5 and P6Analog output	

### ③Directions of Parameter P2 [Light-load parameter setting]:

Setting	Explanation	Default Setting	User Setting
00~30	Light load signal output.	05	

### ④Directions of Parameter P3 [Half-load parameter setting]:

Setting	Explanation	Default Setting	User Setting
P2+1~60	Half-load signal output	30	

### ⑤Directions of Parameter P4[Heavy-load parameter setting]:

Setting	Explanation	Default Setting	User Setting
P3+1~90	Heavy-load signal output	70	

### ⑥Directions of Parameter P5 [Full-load parameter setting]:

Setting	Explanation	Default Setting	User Setting
P4+1~99	Full-load signal output	90	

⑦Directions of Parameter P6 [System overload coefficient]:

Setting	Explanation	Default Setting	User Setting
00~20	Overload > load +(load × P6) %, overload output signal	05	

⑧Directions of Parameter P7 [Operation Status setting of Solid state relay “J1” ]:

Setting	Explanation	Default Setting	User Setting
00~1F	Light load motor output	01 Light-load action close	

⑨Directions of ParameterP8 [Operation Status setting of Solid state relay “J2” ]:

Setting	Explanation	Default Setting	User Setting
00~1F	Full load motor output	04(Full- load dynamic close)	

⑩Directions of Parameter P9 [Operation Status setting of Solid state relay “J3” ]:

Setting	Explanation	Default Setting	User Setting
00~1F	Over load motor output	1F(Over- load dynamic close)	

⑪Directions of Parameter D [Displacement-expanding Setting]:

Setting	Explanation	Default Setting	User Setting
01	Close displacement, 10mm effective	01	

Note: ① If the setting value is not specified, the weighing device will not work normally.

②During the regular maintenance of the elevator, the self-learning work of the weighing device should be carried out again.

## Explanation of Displaying Code:

6、System Normal Operation Code: ( “W” is the present effective load)

Display Code			Indication	
System displays 〔L*〕	L0	No-load car	Output No-load signal	No-load: $00 \leq W \leq \text{Rated-load} \times P2\%$
	L1	Light-load car	Output Light-load signal	Light-load: $\text{No-load} < W \leq \text{Rated-load} \times P3\%$
	L2	Semi-load car	Output Semi-load signal	Semi-load : $\text{Light-load} < W \leq \text{Rated-load} \times P4\%$
	L3	Heavy-load car	Output Heavy-load signal	Heavy-load : $\text{Semi-load} < W \leq \text{Rated-load} \times P5\%$
	L4	Rated-load car	Output Rated-load signal	Rated-load : $\text{Heavy-load} < W \leq \text{Rated-load} + \text{Rated-load} \times P6\%$
	LF	Over-load car	Output Over-load signal	Over-load: $W > \text{Rated-load}$
For user to save: the code of this elevator				Rated-load Compression:      mm

## 7、Code for Other Operation and Failures

	Display Code	Indication	Solution
1	YS	System Startup	
2	Pc	System Resetting	
3	PP	Get into the status of operation parameters modification	
4	PL	Self-learning no-load parameter (static display indicates ready state, flashing display indicates complete detection)	
5	PH	Self-learning rated-load parameter (static display indicates ready state, flashing display indicates complete detection)	
6	LL	Installation      and Too big Positioning	Move this device closing to the magnet

	Display Code	Indication		Solution
7	LH	positioning	Too small Positioning	Move this device away from the magnet
8	Lo		Accurately Position	
9	LP		Interior Auto Correction	
10	P*	System Configuration Indication		
11	Pn	Saved		
12	EA	Saving Failure		Modify the operation parameters
13	EJ	Without this system setting		Check system setting value
14	ED	Car platform deformation deficient		Affirm elevator in the condition of rated load
15	EC	Car platform deformation overflowing		Damping rubber is too soft, adjust PD
16	EH	Incorrect installation place of the magnet		Check the magnet installation place
17	EL	Incorrect installation place of the magnet		Check the magnet installation place,pay special attention to polarity and distance.

## How to do?

### 8、Brief Analysis of Other Conditions:

①After installation of this weighing device, weighing signal changes in the course of operation?

The elevator load output value is not held after elevator starts, adjust the relative items of the inverter and controller.

②After long-term of operation, system no load zeroing point appears larger deviation?

May be caused by the reason described in section 3,Chapter 3. Set system Autotuning mode to calibrate again

③After the elevator weighing is changed from heavy load to light load, heavy load signal is still displayed?

The movement of the moveable car platform is blocked, it is not reset after pressing. Solute the relevant

mechanic problems.

④System output signal doesn't change linearly along with the change of load?

Check the structure of the moveable car platform, pay more attention that there should only be one pair of damping rubber or spring moving relatively to the moveable car platform.

⑤During the system operation, analog output is abnormal or system resetting or speed-regulator cooperation is abnormal?

It may be caused by system power source series interference. Select another group of power to supply the system, or to provide an exterior power of AC/DC 24V/300mA to supply.

## 9、How to set an elevator with known “no-load→rated load” compression deformation?

For example: The max “no-load→rated load” compression deformation of this elevator is 5.8mm.

Operation

- 1.Modify “P0=58” and save it. Refer to chapter 5;
- 2.After system restarting, [LP] is displayed. Wait until [LL], [Lo] or [LH] is displayed;
- 3.When the car is empty, adjust system installation position to make it display [Lo], fasten it;
- 4.When [Lo] is displayed, press [▲] and [▼] simultaneously, system begins to autotune no-load operation parameters;
- 5.Flashing shows [PL] 5 seconds later, All the self-learning work has been completed.

## 10、How to do Re-Autotune operation for system?

Method 1: Simultaneously press [▲] and [▼] on system control panel to power on. This moment, system aglitter displays [PP] and [P-]. Keep 15 seconds, system will display [Pn]. On that occasion, all operation parameters reset to default settings.

Method 2: Modifying parameter P0=0A or user specified operation code will reset system immediately to default status. But for users with specified code. The method is mentioned in Chapter 5.

## 11、How to modify output status of a system after autotuning is finished?

Modify the corresponding controlling parameters of parameter P respectively. The method is mentioned in

Chapter4.and 5.

### **12、How to adopt 20% rated load for rated load autotune?**

Modify P0=04. After [Lo] positioning and no-load [PL] autotuning, in the period of system displaying [PH], load 20% of the rated load, press【】, system displaying [L1] means the end of adjustment. This is an auxiliary method when 100% autotuning can be done.

### **13、The compression of car damping rubber exceeds the sensor inspection range?**

Before autotuning, be assure to select “PD” = “02/03” and save it. Then, readjusting the installing position of the sensor is OK (See parameter PD for more details).

### **14、On adopting operation of “load increasing, displacement aloofing” method?**

Before autotuning, be assure to select “PD” = “1\*” and save it. Then, readjusting the installing position of the sensor is OK.

## **System Characteristics**

---

### **15、Working principle of “EWD-H-SJ3” elevator weighing device**

With the constantly development of elevator technology, the impact of elevator weighing device on elevator performance can not be neglected. The requirement of elevator for weighing devices with high accuracy, high reliability and multi-functions becomes extremely urgent. Presently, the progress of sensor technology and microcomputer is ceaseless. With the adoption of highly accurate Hall sensor, the change of displacement along with car platform load can be checked. Meanwhile, with the adoption of single chip microprocessor, scientific calculation can be done, making this device weigh the elevator car load effectively. With the cooperation of EWD —AL1 remote signal transferring device, analog or digital signal can be transferred far away, largely enlarging the user’ s application range and decreasing the additional cost in the course of use.

### **16、Main property**

(1)Working in a contactless and inductive way. No mechanical movement. Solid-state relay outputs. Being directly installed in the original place of overloading switch. No necessity of changing the mechanism of elevator car.

- (2) The whole system is designed in the waterproof structure with small overall size, easy installation and adjustment and simple structure.
- (3) Wide induction range, high accuracy positioning, intelligent temperature compensation making the range of operating temperature wider.
- (4) The inner core consists of Hall sensor of high accuracy and single-chip microprocessor of high efficiency. All parameters may be set on the field.
- (5) Adopting strong inductive magnet, improving the anti-interference capability of the system to the utmost.
- (6) Each set of products undergo a rigorous aging process to ensure reliable work.
- (7) System based on mathematical equations for scientific computing, automatic detection error correction
- (8) On-site adjustment is easy, either by autotuning or by manual displacement setting.
- (9) The independent development of the programmable output signal control method can be used for all kinds of traction elevator with moveable car platform.

## 17、Technical specifications:

1.	Application	Being applicable to all moveable car platform elevators , with an auto inspection range of $(2.00\text{mm} \leq \text{car platform movement} \leq 10.00\text{mm})$ ; manual setting displacement range 2.5~9.9mm (relate to parameter PD)		
2.	Sensitivity	Elevator rated load/200 (With the rated load of 1T, it is 5.0Kg)		
3.	System Error	$\leq 1.5\%$ (-20~55℃)		
4.	Non-Linearity	$\leq 1.0\%$		
5.	Output Mode:	Solid-state Relay	Programmable universal signal	① 3/5 channel programmable output modes are: No load, light load, semi full load, heavy load, rated load, overload (customer may set the changing range freely). ② Each channel can be programmed as dynamic Close or Open contact. ③ Contact Capacity:DC/AC 32V/15mA。

## EWD-H-SJ3 User manual for technical documents of intelligent elevator weighing device[V2.2]

6	Working Temperature:	-20~55℃
7	Relative Humidity:	20%~99%RH
8	Reaction Time	≤0.25 Seconds
9	Power Supply:	AC/DC 24(±10%)V / 150mA
10	Installation Place:	Moveable car platform of elevator
11	Overall Size:	45×45×90 mm3

●\*: The intension exceeding the limit parameters listed above may result in the abnormality or permanent damage to the system.

## Promise

- (1)If this system appears any quality problem of product itself in 1 year after delivery, it will be replaced freely (damage of the product seal will not be dealt with) 。
- (2)For any requirement of special functions, make it out by mail.
- (3)Any system abnormality in adjustment or operation, please contact our company directly.

## Others

1.Accessory	User's Manual	1 piece	Fixing Screw set	2 sets
	Inductive magnet [20×20×4mm3]	1 piece		

2..address book:

029-88416613 /85565714/85568478

7D , Block A, Olympic Building, 14th Chang  
An North Road, Xi'an  
710061

029-85565714-886

Technical support:008618092639752/008618092639750