

EWD-RL-SJ3

User's Guide

(Version 2.2)

XIAN EXCELLENT ELECTROMECHANICAL CO., LTD

Table of Contents	Product Overview	1、Product Appearance and Interior Structure	Page2
		2、Description of system controller terminals	Page5
		Installing Scheme of “Disc” XCL-Y/8625 type Sensor	Page3
		Installing Scheme of Character “—” XCL-T/A type Sensor	Page4
	Installation & Adjustment	3、System Structure and Installation Schematic Diagram	Page6
		4、Installing Method of Sensor and Controller	Page6
		5、System Adjustment and Explanation	Page7
		①.Initialization	Page7
		②.No Load Autotune Operation Mode	Page8
		③.Rated Load Autotune Operation Mode	Page8
	Implication and Adjustment Method of the Operation Parameters	6、Adjustment of the System Parameters	Page9
		7、Explanation of the Meaning of Parameter P	Page10
	Indicating Code Explanation	8、Explanation of System Normal Operation Code	Page13
		9、Explanation of the Code of Other Operations and Fault	Page13
	How To Do?	10、Brief Analysis of Other Status	Page14
		11、How to repeat the Autotune operation for the system?	Page15
		12、How to do Rated Load Autotune by adopting 20% rated load?	Page15
	System Characteristics	13、Working Principle of “EWD-RL-SJ3” Elevator Weighing Device	Page16
		14、Main characteristics	Page16
		15、Technical Specifications	Page17
	Promise		Page 19
	Others		Page 19
	Attached Drawings		
	Attached Sheets		P 21-30

Caution: This system is applicable an elevator with fixed car platform. Before use, be sure to read the following sections carefully.

Note: Under any condition, our part is just responsible for the quality of product in the period of guarantee service.


Declaration: For the reason of technology advancement, our company reserves the right of improving product. As for the relevant technical parameters, Please refer to the technical handbook delivered with the product.

PRODUCT OVERVIEW







1. Product Appearance and Interior Structure:

Schematic Diagram of Controller Appearance

See Fig[1]



Sensor models and appearance:

Sensor profile							
Nami ng	type	XCL-Y/8625	XCL-ZL/W	XCL-T/A	XCL-T/B	XCL-ZL/P2	XCL-ZL/P3
	Dimensio ns and mounting methods	See attached page for details					

2.Schematic Diagram of System Interior See “Fig[1]”

	Function		Description
PG	Connect system load sensor		
PJ. 1 ~2	J1: Light load output, Dyn open/Close		Max load capacity DC/AC 48V/500mA
PJ. 1 ~3	J2: Full load output: Dyn open/close		
PJ. 1 ~4	J3: Over load output: dyn open/close		
PJ. 5	Analog 0~10V output ports		Used for governor torque compensation
PJ. 6	Analog com port		
PM. 1~2	+	For fuzzy intelligence compensation	Compensate for landing deviation
	-		
PM. 3~4	+	Used to lock the output of the weighing device	See: attached figure
	-		
PV	Weighing device power supply port		AC/DC 24V/150mA

⚠ Absolutely don't connect the output terminals (except “PV”) of this device to the external power source directly and

the resulted permanent damage to the device is beyond our responsibility.

Installation and Adjustment

3. Schematic Diagram of System Structure and Installation


Schematic diagram of the whole machine: See Figure [1] for controller part; See sensor selection for the sensor section.

4. Install Method of Sensor and Controller


1. The controller should be installed in the control cabinet of the machine room, and it is better not to be close to the elevator electronic weighing device transformer, governor and other equipment. In all cases, sensors and controllers shall be installed away from heat sources;
2. The connection between the sensor and the controller, it is best not to 110V, 220V and other power supply in the same wiring slot;
3. Power on the weighing device after confirming that the check is correct, and the controller should be displayed in the corresponding working mode.

5. System Adjustment Method and Description (Autotune Operation)

①Initialization: Selection of Compensation Method



② Lock car self-weight, self-learning no-load working mode:



③ Rated Load Autotuning Operation Mode:

- ① System displays **【PH-01】** .
- ② Load elevator car to effective rated load condition(for elevator of rated load 1000Kg, loading 1000Kg is necessary) or 20% effective load (for "P1=02").
- ③ Press key **【▼】** ; When **【PH】** displayed aglimer, inspection is finished.

④ The end of autotuning :

System resets automatically, **【FY】** → **【J2】** will be displayed. **By now, the whole autotuning course is finished.** (**【J1】** is displayed for 20% effective load).

5. System adjustment under other conditions:

For following reasons, the parameters of this system need re-modifying in the way described above.

- ① Elevator car decoration changing causes its dead weight change.
- ② Larger unbalance appears among traction ropes.
- ③ Weighing sensor becomes flexible.
- ④ Overrunning at the top or at the bottom appears.

Operation Parameters Adjustment and the Implication

6. System Operation Parameters Adjustment

- ① Simultaneously press **【▲】** and **【▼】** on system control keypad to power on , this moment **〔PP〕** will be displayed alternately, that means entering operation parameters modifying status.
- ② Release **【▲】** and **【▼】** buttons, system will display **〔P*〕** and **〔**〕** alternately. **〔P*〕** is an indication of system operation parameters; **〔**〕** is the interior data value of **〔P*〕** .
- ③ When displaying **〔P*〕** , press **【▼】** , indication of system operation increases; press **【▲】** , indication decreases.
- ④ When displaying **〔**〕** , press **【▼】** , data value increases; press **【▲】** , data value decreases.
- ⑤ Release buttons, system displays operation indication and configuring data alternately.
- ⑥ To modify other configuring datum, repeat the operation of 3, 4, 5.
- ⑦ At the moment when system displays **〔P*〕** , Simultaneously press **【▲】** and **【▼】** , system will save modified datum for future use.

This moment, system displays **〔Pn〕** for 1 second. System operation parameters modification is completed. (**Note: * is any of the hexadecimal value in the range of “0~9,A~F” .**)

Example: Modify parameter P1 to 10; (System Setting effective load of 1000Kg)

Example: Modify parameter PJ to 03; (Pj3.1~2、Pj3.3~4 enabling for low voltage level compensation signal)

- ① Simultaneously press **【▲】** and **【▼】** on system control keypad to power on , this moment **〔PP〕** will be displayed aglimer, that means entering modifying status.
- ② Release **【▲】** and **【▼】** buttons, system will display **〔P*〕** and **〔**〕** aglimer
- ③ When displaying **〔P0〕** , press **【▼】** to increasing it to **〔P1〕** ;
- ④ Release button **【▼】** , system alternately displays **〔P1〕** and **〔**〕** .

⑤When displaying [**], press [▲] and [▼] to regulate its value as [10] .

⑥Release button, system alternately displays [P1] and [10] .

⑦At the moment when the weighing device displays [P1], press the [▲] and [▼] buttons at the same time, and the weighing device memorizes and revises the data. At this time, the weighing device displays [Pn] for 1 second. The working parameters of the weighing device have been revised.

7. Implication of parameter P: Under normal circumstances, users do not need to modify the parameters after "P0", and the weighing device will correct itself during the self-learning period.

①Directions of Parameter P0[System Operation Mode]:

Setting	Explanation	Default Setting	Normal Value
00	Normal Operation (Automatically modify by system after autotune.)	01 (Sensor positioning)	00 System Auto Modifying
01	Sensor positioning, System autotuning.		
09	Select "王" type intelligent sensor abnormal handling option		
0A	The weighing device is set to the factory setting		

②Directions of Parameter P1 [Rated Load Setting Mode]:

Setting	Explanation	Default Setting	User' s Setting
01/02 or 05~55 ×100Kg	01--- "100% Rated load,floor by floor" Autotuning Mode; 02--- "20% Rated load,floor by floor" Autotuning Mode; **---Select rated load setting mode(Not Recommended)Example: "10" means rated load of 1000Kg. There is a certain error in this method.	01 (Rated Load Autotuning)	

③Directions of Parameter P2、P3、P4、P5[Reserved]:

④P6 Parameter description [Relay "J1, J2, J3" logic state setting]

Setting	Explanation		Default Setting	Default Setting
	Higher Bits	Lower Bits		

EWD-RL-SJ3 Intelligent elevator weighing device technical document user manual[V2.2]

00~17	0--- Select 0~10V	Contact condition	J3	J2	J1	03 (J1,J2 Relay output,J3 Dynamic open output, analog quantity 0~10V is valid)	
	1--- Select 10~0V	3	Dynamic break	Dynamic closing	Dynamic closing		

⑤Directions of Parameter P7

Setting	Explanation		Default Setting	User' s Setting
00~99 A0~A9 b0~b9 C0~C5	When Load \geq Rated load \times P9%, “J1” signal is output.		10 Set “J1” to actuate at 10% of rated load	
	00~99: Actuating for 0~99% rated load;			
	A0~A9: Actuating for 100~109% rated load;			
	Example	P7=80: For effective load of 1T, system actuates at 800Kg.		
		P7=A5: For effective load of 1T, system actuates at 1050Kg.		

⑥Directions of Parameter P8 [Operation Range Setting of Relay “J2”]:

Setting	Explanation	Default Setting	User' s Setting
The same as P7	The same as P7	80 “J2” Setting: actuating for 80% Rated Load	

⑦Directions of Parameter P9 [Operation Range Setting of Relay “J3”]:

Setting	Explanation	Default Setting	User' s Setting
The same as P7	The same as P7	A5 Setting “J3”: actuating for “J3” 105% Rated Load	

⑧PA Parameter description [Reserved]:

⑨PB Parameter description [Reserved]:

⑩PC Parameter description [Reserved]:

Attention :

- ① If the setting value is not specified, the weighing device will not work normally.

- ② The no-load automatic zero parameter should be used carefully because of the diversity of the no-load point drift of the elevator; You are advised to disable or allow this function based on the elevator status.
- ③ Even if the no-load automatic zero function is opened, the weighing device should be re-carried out during the regular maintenance of the elevator Self-learning work.

Explanation of Displaying Code:

8.System Normal Operation Code:

〔J0〕	〔J3〕	〔J2〕	〔J1〕
No Relay Output	Output of Relay J3	Output of Relay J2	Output of Relay J1
	The default load is 105% broken	The default load is 80% action	The default load is 10% action
1.Press【▲】, “HJ※※※※” displaying indicates present car effective load. Such as displaying“HJ0520” means load of 0520Kg.			
2.During fuzzy compensation, displaying “0.0.” means compensation is “Enable”, “0.1.” indicates elevator entering modifying zone.			

9.Code for Other Operation and Failures

	Display Code	Indication	Solution
1	FY	Starting indicator of weighing device, flashing display indicates that P0 setting of weighing device parameter is incorrect	
2	Pc	Sensor Resetting	
3	PP	Get into the status of operation parameters modification	
4	PL	Autotuning No load parameters	(Still Displaying indicates preparation status, flashing displaying indicates the end of inspection)
5	PH	Autotuning Rated load parameters	
6	LL	Installation and positioning Too big Positioning	Sensor having no load
7	LH	Too small Positioning	Sensor overload
8	Lo	Accurately Positioning	
9	LP	Interior Auto Correction	
10	LY	Forcibly skip sensor interior auto correction	

	Display Code	Indication	Solution
11	P*	System Configuration Indication	
12	Pn	Saved	
13	EA	Saving Failure	Modifying operation parameters
14	EJ	Without this system setting	Check System Settings
15	EH	Applied Overflowing Pressure	Sensor Standing Pressure beyond its bearing range
16	EL	Applied Insufficient Pressure	No applied pressure to Sensor
17	EF	Memorizing abnormally	Repeat this operation.

How to do?

10.Brief Analysis of Other Conditions:

(1) Bad system Operation Stability with the main indication of large output fluctuation in the condition of fixed load and elevator motionless?

Check if PV power supply source fulfils system requirements?

(2) After long-term of operation, system no load zeroing point appears larger deviation?

May be caused by the reason described in section 4 , chapter 5. Set system Autotuning mode to calibrate again, or startup parameter “PE≠0” to realize the function of system no load auto zeroing.

Poor Landing Compensation consistency?

Modify lower bits of Parameter “P4” .

(4) Traveling Up and down with the same load and stopping at the same floor, but the weighing result is different?

Lift rope pull is not symmetrical, adjust please.

② Elevator guide shoes are too tightened, running friction is large. It is recommended to adjust or modify relevant mechanical part to make it move flexible, then operate the system to autotune again.

(5) System output signal doesn’ t change linearly along with load?

Maybe system sensor damaged.

(6) How to descry present effective load of elevator car?

In the period of system normal operation, press button 【 】. This moment, system displays [HJ] → [**] → [**]

.For example : displaying [HJ]→[09]→[50] indicates a car with rated load of 1000 Kg presently bearing an effective load of 950Kg.

If elevator effective load is not 1000 Kg, it may be decided after system autotuning operation is finished by modifying parameter “P1” .

Because of various impacts from outer environment, displayed data may fluctuate in a small scope.

(7) When elevator is motionless, weighing signal is normal. But in the course of door opening, it is abnormal?

Elevator door operation system causes relative car weight offset. It may be controlled by adopting door opening/closing relay output signals+ door lock signal jointly participating system PC.3~4 locking control.

(8)During system operation, analog output is abnormal, repeatedly resetting or abnormal coordination with speed regulator?

May be caused by crossing and interfering system power source. Select another set of power source to supply system, or equip another AC/DC 24V/300mA exterior power source to supply power.

11. How to do Re-Autotune operation for system?

Method 1: Simultaneously press 【▲】 and 【▼】 on system control panel to power on. This moment, system aglimmer displays [PP]. Keep 15 seconds, system will display [Pn]. On that occasion, all operation parameters reset to default settings.

Method 2: Modifying parameter P0=0A will reset system immediately to default status. But for users with specified code, it is necessary to modify parameter P0 as appointed code. Detailed operation is described in chapter 6.

12. How to adopt 20% rated load for rated load autotune?

Modify parameter "P1=02" after the weighing device displays $\llbracket Lo \rrbracket$. The no-load self-learning of the weighing device is completed in accordance with the "Five" chapter. During the display $\llbracket PH \rrbracket$, the weight equivalent to 20% of the rated load of the elevator should be added to the car for the load self-learning operation. After the operation is completed, the display $\llbracket J1 \rrbracket$ will be displayed.

System Features

13. Working Principle of “EWD-RL-SJ3” Elevator Weighing Device

With the constantly development of elevator technology, the impact of elevator weighing devices on elevator performance can not be neglected. The requirement of elevator for weighing devices with high accuracy, high reliability and multi functions becomes extremely urgent. Nowadays, the progress of sensor technology and microcomputer is ceaseless. Inspecting electric signals producing by elevator car load changing with high accurate “Disc” type loading sensor, meanwhile, performing scientific calculation and procession with single-chip microprocessor, the aim of weighing elevator car effective load is fulfilled.

14. Main Characteristic:

- ① Selecting directly-compressing “Disc” type load sensor, it is unnecessary to change the pull rod of traction rope shackle.
- ② Weighing range is wide (effective load of 300Kg~5000 Kg), high-accuracy position, intelligent temperature compensation.
- ③ Inner core consists of highly accurate load sensor and high performance single-chip micro-computer. All operation parameters can be set on field.
- ④ System may do scientific calculation according to mathematical equations with the function of no-load auto zeroing, automatically modifying measuring error.
- ⑤ The capability of fuzzy compensation improves the requirement of elevator for high accuracy weighing signals.

- ⑥Being provided with load setting or 20% or 100 %rated load autotuning sub-function under the condition of auto removing dead weight. It is easy to fulfill user's requirements.
- ⑦Autotuning for on-site adjustment makes it easy to be adjusted.
- ⑧Having the function of operation parameters auto modification and fuzzy landing compensation function.
- ⑨The whole shoot starts from users' point of view, easy installation and adjustment, decreasing users' additional cost in use, high ratio of performance to price.

15. Technical Specifications: :

1.	Application Range		Being applicable to all traction elevators with fixed car platform with the load of 500kg~3000/5000kg	
2.	Landing Compensation Method		Auto adapting intelligent fuzzy compensation	
3.	Sensitivity		Elevator Rated Capacity/200 (Example: The rated capacity is 1000kg, and the sensitivity is 5kg) [This data may be affected by elevator mechanical performance.]	
4.	System Error		$\leq 0.5\%$ (5~40℃)	
5.	Non-linearity		$\leq 0.5\%$	
6.	Output	Relay	Programmable common signals:	①2-channel programmable output modes are: No load, light load, semi full load, heavy load, rated load, overload (customer may set the changing range freely). ②Each channel can be programmed as dynamic Close or Open contact. ③Contact Capacity: DC/AC 48V/100mA。
	Mode:		Analog Output:	It performs linear change (0~10V) when Elevator load is changing from “no load~rated load” .
7.	Operation Ambient Temperature		Temperature:-20~55℃	
8.	Relative Humidity		20%~90%RH	
9.	Reaction Time		≤ 0.3 Second	

10.	Power Supply:	AC/DC24($\pm 10\%$)V / 200mA
11.	Install Position	Sensor Section: At the place of traction rope shackle Controller Section: Control Cabinet in machineroom. See the attached figure for installing dimensions.
12.	Overall Size	Sensor Section: See the figure; Controller Section: See the figure

☛: The intension exceeding the limit parameters listed above may result in the abnormality or permanent damage to the system.

Promise

- (1)If this system appears any quality problem of product itself in 1 year after delivery, it will be replaced freely (damage of the product seal will not be dealt with) 。
- (2)For any requirement of special functions, make it out by mail.
- (3)Any system abnormality in adjustment or operation, please contact our company directly.

Others:

1.Packing List:	Controller	1set
	M4*40 mm Fastening Screw sets	2 sets
	Load Sensor	1set
	Load Sensor attachment	6 sets
	User' s Guide	1copy

2.Address book: : Xi'AN EXCELLENT ELECTROMECHANICAL CO.,LTD


☎ : (029)88416613, ☎ : 7D, Block A, Olympic Building, 14th
85565714, 85568478 Chang An North Road, Xi'an, Shaanxi,
China

☎ : (029)85565714-886 ☎ : 710068

Technical Support: 0086-18092639750 0086-18092639752

EWD-RL-SJ3 Intelligent elevator weighing device technical document user manual[V2.2]

Att. Fig: Wiring Method of Terminal PM and PX Under Auto accommodating fuzzy Landing compensation



Recommended Application Range of this mode: All elevators with better mechanical installation characteristic.


- Notes:**
1. Directly parallel connect PX1~2 and PM1~2 to corresponding electric circuit. If user selects “mid landing” position signal, more accurate compensation effect may be received.
 2. If the common polarity of elevator signals is +COM (power source), reversely connecting the terminals of PX and PM, i.e., exchange PM.1 and PM.2. The rest may be deduced by analogy
 3. Voltage of terminal COM should be in the range of “DC12~32V” .

Attached document:


Load sensor dimensions and installation

1. XCL-Y/8625 loading Sensor size and installation method:


1.1 size (range: 12KN、22KN、30KN、40KN、50KN、70KN)



Bar size chart





1.2 Install Method




2. XCL-ZL/W Load Sensor size and installation method:

2.1 Load Sensor demensions:



传感器量程	传感器相关尺寸	
KN	A	B
20	216	192
50	260	238


2.2 Install Method



Note: During installation, be sure to use Ø6 wire rope to connect the safety ring and secure it on the support of the tractor, in case the sensor falls off during installation and debugging, to ensure personal safety!

3. XCL-T/A Load Sensor size and installation method

3.1 Load Sensor dimensions:




传感器量程	传感器相关尺寸				
KN	H	A	B	C	螺纹孔深度
10	41	25	8	12.5	通孔
15	41	25	8	12.5	通孔
20	41	25	8	12.5	通孔
30	48	35	10	12.5	通孔
50	48	35	10	12.5	通孔
70	60	35	8	17	18
100	60	35	8	17	18
150	70	35	8	21	18

3.2 Install Method:



4. XCL-T/B Load Sensor size and installation method

4.1 Load Sensor dimensions:




传感器量程	传感器相关尺寸			
KN	H	A	B	螺纹孔深度
30	48	10	12.5	通孔
50	48	10	12.5	通孔
70	60	8	17	18
100	60	8	17	18
150	70	8	17	18

4.2 Install Method:




5. XCL-ZL/P2 Load Sensor size and installation method:

5.1 Load Sensor dimensions (range: 5KN、8KN) : 5.2 Install Method



6. XCL-ZL/P3 Load Sensor size and installation method:

6.1 Load Sensor dimensions (range: 5KN、8KN) :



6.2 Install Method

