

# **EWD-RLG-SJ3**

## **User's Guide**

**(Version2.0)**

**XIAN EXCELLENT ELECTROMECHANICAL CO., LTD**

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

Table of Contents	<b>Product Overview</b>	1.Product Appearance and Type Nomination .....	<i>Page 3</i>
		2.Installing Method and Working Principle .....	<i>Page 4</i>
		3.Schematic Diagram of the Controller Appearance .....	<i>Page 6</i>
		4.Schematic Diagram of the Sensor Appearance and Installing Method .....	<i>Page 7</i>
		A. Standard “Disc” type Intelligent Load Sensor .....	<i>Page 8</i>
	B. Standard Character “王”type Intelligent Tension Sensor .....	<i>Page 8</i>	
	C. Standard Character “—” type Intelligent Load Sensor .....	<i>Page 8</i>	
	<b>Installation &amp; Adjustment</b>	5.System Structure and Installation Schematic Diagram .....	<i>Page9</i>
		6.Install Method of Sensor and Controller .....	<i>Page 10</i>
		7.System Adjustment and Explanation ( <b>Autotune</b> ) .....	<i>Page 13</i>
		①.Initialization: Selection of Compensating Method .....	<i>Page 13</i>
		②.Lock the Dead Weight of the Car .....	<i>Page 15</i>
		③.No Load <b>Autotune</b> Operation Mode .....	<i>Page 15</i>
	<b>Implication and Adjustment Method of the Operation Parameters</b>	④.Rated Load <b>Autotune</b> Operation Mode .....	<i>Page 16</i>
		8.Adjustment of the System Parameters .....	<i>Page 13</i>
		9.Explanation of the Meaning of Parameter <b>P</b> .....	<i>Page 14</i>
<b>Indicating Code Explanation</b>	10.Explanation of System Normal Operation Code .....	<i>Page 19</i>	
	11.Explanation of the Code of Other Operations and Fault .....	<i>Page 19</i>	
<b>How To Do?</b>	12..Brief Analysis of Other Status .....	<i>Page 20</i>	
	13.How to repeat the <b>Autotune</b> operation for the system? .....	<i>Page 21</i>	
<b>System Characteristics</b>	14.How to do Rated Load <b>Autotune</b> by adopting 20% rated load? .....	<i>Page 22</i>	
	15.Main characteristics .....	<i>Page 22</i>	
<b>Promise Others</b>	16.Technical Specifications .....	<i>Page 23</i>	
	Attached Drawings	[1]、 [2]、 [3] .....	<i>Page 26-38</i>

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

**Caution:** This system is applicable an elevator with **fixed car platform**. Before use, be sure to read the following sections carefully.

**Note:** Under any condition, our part is just responsible for the quality of product in the period of guarantee service.

**Declaration:** For the reason of technology advancement, our company reserves the right of improving product. As for the relevant technical parameters, Please refer to the technical handbook delivered with the product.

### System Overview

#### 1.Product Appearance and Type Nomination:

##### 1)Sensor of XCL-Y/8625XCL-ZL/W/ XCL-T/A

Sensor Appearance									
		Notes	For directly connected sensor, default length of the cable supplied with it is 8 meers						
Product Naming	Ordering Type	XCL-Y/8625		XCL-ZL/W		XCL-T/A		XCL-ZL/P	
	Sensor Type	“Disc” type Load Sensor		Character “王”type Tension Sensor		Character “—”type Load Sensor		Steel band Sensor	

##### 2) Controller of EWD-RLG-SJ3

Install at the rope hitch in machine-room	<b>EWD-RLG-SJ3</b>
Application Range	Apply to "bottom" fixed elevator, sensor default built-in 8 m cables, customers can contact with our company custom cable according to the


## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

		actual demand actual length.		
Controller Appearance				
Product Naming	Ordering Type	EWD-RLG-SJ3/ XCL-Y/8625	EWD-RLG-SJ3/ XCL-ZL/W	EWD-RLG-SJ3/XCL-T/A
	Assorted Sensor	XCL-Y/8625	XCL-ZL/W	XCL-T/A

### 2. Installing Method and Working Principle of “EWD-RLG-SJ3”

With the constantly development of elevator technology, the impact of elevator weighing device on elevator performance can not be neglected. The requirement of elevator for weighing devices with high accuracy, high reliability and multi functions becomes extremely urgent. Presently, the progress of sensor technology and microcomputer is ceaseless.


With the adoption of highly accurate intelligent ”tension” or ”load” and “stress” sensors, the electric signal produced by elevator car load changing is tested and inspected. System sensor installed at the traction rope hitch: Type“EWD-RLG-SJ3”: There is an 8~10-meter-long signal transmitting cable with the sensor. And the single-chip built-in the controller may do scientific



## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

calculations fulfilling the aim of weighing the effective load in elevator car.

### 3. Illustration of the Appearance of Controller:



Note: ① Hereinafter, Pj1.1 means the 1st place of Pj1 wiring port, successively analogizing. Its arrangement in the control is from left to right. ② The size of the whole set is shown in section 13, chapter 19 in detail. ③ Terminal wiring is described in Chapter 5.

### 4. Illustration of the Appearance of Sensor and Install Method:

A: XCL-Y/8625 “Disc” type load sensor size drawing and installation (see the attached sheet 1.1 and 1.2)


B: XCL-ZL/W “王” type load sensor size drawing and installation (see the attached sheet 2.1.1; 2.1.2 and 2.2)

C: XCL-T/A “—” type load sensor size drawing and installation (see the attached sheet 3.1.1; 3.1.2 and 3.2)

### 5.Description of the System Controller Terminals:

**Being effective when selecting floor-by floor compensation methods:**

1. If floor-by-floor compensation is unnecessary, this port is unwired; ;
2. Adopting fuzzy compensation, this port is unwired, refer to attached Figure[1];
3. Adopting “up and down leveling” compensation method, refer to attached Figure [2];
4. Adopting “door zone + traveling direction” compensation method, refer to attached Figure [3];
5. Triggering Voltage of PX.1~2、PX.3~4 is DC12~32V, the way of triggering method is decided by the manual setting of “PII”
6. The compensation method is differentiated by the system automatically after the wiring of PC ports is completed, and the results will be stored inparameter “P5”;
7. PX.5~6 is the control signal for output locking to be connected to door interlocking circuit Note: With the adoption of landing compensation, be sure to power on the circuit.



## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

### Detailed Explanation of the Controller Terminals:

		Function	Explanation			
<b>PJ</b>	Switching	1	COM of J1~2 Relay	In coordination with Pj.2~4 to produce effective logic	1.Effec : Be programmed as“no load ~ overload”output signals to participate in elevator logic control	
		2	J1 Relay Output Terminal			System Default“J1”: <b>No load</b> Output;
		3	J2 Relay Output Terminal			System Default “J2”: Rated load Output;
		4	COM of J3 Relay			In coordination with Pj.5~6 to produce effective logic
		5	J3 Relay Output Terminal			System Default “J3”: <b>Overload Dyn Close</b> Output;
		6	J3 Relay Output Terminal			System Default “J3”: <b>Overload Dyn Open</b> Output;
	Analog	7	Analog Voltage Output: 0~10V;-10~+10V;0~+5V	Being used for pre-torque compensation for driving system		
		8	COM connected to analog common terminal of speed regulator			
<b>PX</b>	5[+]~6[-]	Lock output signal control terminal. Be connected in system door lock signal circuit, pay attention to connecting polarity.				
<b>PG</b>	To Connect PG to the sensor along with signal cable					
<b>PV</b>	System Power Supplying Terminal: AC/DC24V / 200mA					
<b>PX</b>		<b>Parameter P5=2</b>	<b>Parameter P5=3</b>	<b>Parameter P5=4</b>	1.No wiring: system unnecessary of landing compensation; 2. System may accurately control elevator floor-by-floor compensation to interpolate the dead weight floor error caused by cable, rope and compensation cable; 3.This terminal defaults positive skip of input signal being effective and the enabling method of PX3.1~2、PX3.3~4 depends on parameter "PD". 4.See attached figure for wiring.	
	1[+] ~ 2[-]	Down leveling signal ( Up leveling Sensor)	Signal of Elevator entering leveling zone or door zone			

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

3[+] ~ 4[-]	Up leveling signal (Down leveling Sensor)	Elevator Up traveling Signal	Main floor signal	

- ① Absolutely don't connect the output terminals (except "PV") of this device to the external power source directly and the resulted permanent damage to the device is beyond our responsibility.
- ② Attention: As for the input signal of "PX" terminal, a requirement of polarity is needed, PX.1、3 and PM.1 are "+", and the corresponding circuit voltage should be "DC 12~32V".

## Installation and Adjustment

### 6.Schematic Diagram for System Construction and Installing Method:

- ① Adjust the traction rope, make its consistent each pull
- ② A. "disc" type sensor according to the attached 1.2, using "homemade taper sleeve splint" installed in the elevator car traction taper sleeve parts;  
B. "王" type sensor according to the attached 2.2, installed in the elevator car traction rope near taper sleeve parts;  
C. "一" type sensor according to the attached 3.2, adopts "homemade taper sleeve splint" installed in the elevator car traction taper sleeve parts;
- ③ Controller part should be installed in the engine room control cabinet, it is best not to close to the elevator electric control system of transformer, governor and other equipment. In any case, sensor and controller should be installed far away from the heat source
- ④ Connection between sensor and controller, had better not with 110 v and 220 v power supply in the same wiring slot

## **Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]**

---

⑤ The sensor connection port to connect to controller PG, PV according to system needs access to the power cord at the same time, it is important to note the voltage level

⑥ Sure after checked, the system is powered on display controller shall have the corresponding work

### **1、 Install Method of Sensor and Controller:**

① Adjust traction ropes so that the pull of each rope keeps coincident.

② XCL-Y/8625: “Disc” type sensor is installed at the place of the elevator- car-side traction rope shackle according to Fig. [3A.1] and Fig. [3A.2] with customer-made shackle clamp plate.

XCL-ZL/W: Character “王” type tension sensor is installed at the place of the elevator- car-side traction rope shackle according to Fig. [3B] and refer to it for more details.

XCL-T/A: Character “—” type load sensor is installed at the place of the elevator- car-side traction rope shackle according to Fig. [3D] with customer-made shackle clamp plate.

③ Control Section should be installed in the control cabinet placed in machineroom, being away from equipments such as the transformer, speed regulator of elevator electric control system. Under any condition, sensor and controller should be far away from heat source.


④ It would be better not to put the connecting cable between sensor and controller in the same wire duct with dynamic power of 110V or 220V.

⑤ Connect the sensor wiring terminal to PS terminal of the control, simultaneously, connect power line to PV according to system requirement. Pay attention to the voltage level.

⑥ When no error is inspected, power on the system and the corresponding operation patterns will be displayed on the control.


### **7.Adjustment Method and Description of the System ( Autotune Operation)**

## ① Initialization: Selection of Compensation Method




## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]


### ② Lock the dead weight of elevator car :



### ③ . No load Autotuning Operation Mode:



④ **Rated Load Autotuning Operation Mode:**



⑥ **System adjustment under other conditions:**

For following reasons, the parameters of this system need re-modifying in the way described above.

- 1) Elevator car decoration changing causes its dead weight change.
- 2) Larger unbalance appears among traction ropes.
- 3) Sensor of weighing device becomes flexible.
- 4) Overrunning at the top or at the bottom occurs.

## Operation Parameters Adjustment and the Implication

### 8. System Operation Parameters Adjustment (Annotation: \* represents for a hexadecimal value of “0~9,A~F”.)

- ① Simultaneously press **【▲】** and **【▼】** on system control keypad to power on , this moment **【PP】** will be displayed aglimer, that means entering operation parameters modifying status.
- ② Release **【▲】** and **【▼】** buttons, system will display **【P\*】** and **【\*\*】** alternately. **【P\*】** is an indication of system operation parameters; **【\*\*】** is the interior data value of **【P\*】** .
- ③ When displaying **【P\*】** , press **【▼】** , indication of system operation increases; press **【▲】** , indication decreases.
- ④ When displaying **【\*\*】** , press **【▼】** , data value increases; press **【▲】** , data value decreases.
- ⑤ Release buttons, system displays operation indication and configuring data alternately.
- ⑥ To modify other configuring datum, repeat the operation in item 3, item 4, and item 5.
- ⑦ At the moment when system displays **【P\*】** , Simultaneously press **【▲】** and **【▼】** , system will save modified datum for future use. This moment, system displays **【Pn】** for 1 second. System operation parameters modification of this time is completed.

**Example: Modify parameter PD to 03;** (PX.1~2、PX.3~4 enabling for low voltage level compensation signal)

- ① Simultaneously press **【▲】** and **【▼】** on system control keypad to power on , this moment **【PP】** will be displayed aglimer, that means entering modifying status.
- ② Release **【▲】** and **【▼】** buttons, system will display **【P0】** and **【\*\*】** aglimer
- ③ When displaying **【P0】** , press **【▼】** to increasing it to **【PD】** ;
- ④ Release button **【▼】** , system alternately displays **【PD】** and **【\*\*】** .
- ⑤ When displaying **【\*\*】** , press **【▲】** and **【▼】** to regulate its value as **【03】** .
- ⑥ Release button, system alternately displays **【PD】** and **【03】** .
- ⑦ At the moment when system displays **【PH】** , Simultaneously press **【▲】** and **【▼】** , system will save modified datum for future use. This moment, system displays **【Pn】** for 1 second. System operation parameters modification is completed.

**9.Implication of parameter P:** Normally, it is unnecessary to modify parameter after “P0”. System may automatically modify them in the course of Autotuning.

① Directions of Parameter **P0** [System Operation Mode]:

Setting	Explanation	Default Setting	Normal Value
00	Normal Operation (Automatically modify by system after autotune.)	01 (Sensor Positioning)	00 System Auto Modifying
01	Sensor positioning, system autotuning		
09	Options for dealing with abnormality when Selecting“王”type intelligent sensor.		
0A	Forcibly set system settings as default values		

② Directions of Parameter **P1** [System Rated Load Setting Mode]:

Setting	Explanation	Default Setting	Normal Value
01/02或 05~55 ×100Kg	01— Select“Rated load, floor by floor” Autotune 02— Select“20% Rated load, floor by floor” Autotune; **—Select rated load setting mode(Not Recommended)Example: “10”means rated load of 1000Kg. There is a certain error in this method. <i>Note: This mode is just for type “D” sensor.</i>	01 (Rated load Autotuning)	

③ Directions of Parameter **P2** [The Highest Elevator Landing Setting Mode](Automatically modify them in the course of Autotuning by system):

Setting	Explanation	Default Setting	Normal Value
01~32	Setting elevator landings: Selection of 01 means ceasing floor compensation function. Input signal of PX is ineffective this time.	A0(landings)	System automatically modifies them in the course of Autotuning.

④Directions of Parameter **P3** [Setting Elevator Shutdown at Main Floor]:

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

Setting	Explanation		Default Setting	Normal Value
	Higher Bits	Lower Bits		
01~19	0—"PX.5~6" effective for Low Voltage Level; 1—"PX.5~6" effective for High Voltage Level;	Setting elevator main floor. Example: Selecting 2 means there is a basement floor for this elevator.	01(landing) Effective when switched on, and with the basement floor is main floor.	System auto modification in fuzzy compensation autotuning
	Example: Selecting 12 means "PX5~6" effective for Low Voltage Level and there is a basement floor for this elevator.			

### ⑤ Directions of Parameter **P4** [Time Parameter for Floor-by-floor Compensation]:

Setting	Explanation		Default Setting	Normal Value
	Higher Bits	Lower Bits		
00~99	Anti-interference protection time of each floor : 0~9×0.5 Second;	Control Factor of fuzzy compensation: 0~3	12 Anti-interference protection time of each floor is 2.0 seconds ; Control Factor of fuzzy compensation is 2.	
	0-Not Enabling protection time			

### ⑥ Directions of Parameter **P5** [Selection of Floor compensation input signal function] (Automatically modify in the period of Autotuning by system):

Setting	Explanation					Default Setting	Normal Value
	00	01	02	03	04		
00~03	Allow auto deciding compensation method	Disable	up/down leveling step counting control	Door zone + running direction Control	Fuzzy compensation	00 (Auto Measuring)	Auto modified by system in the period of [Lo] displaying.
	<b>Notes:</b> 1. See Section 1, Chapter 8 and attached drawings for more details; 2. Elevator of serial communication control may use "03" or "04" operation method. Running direction Signal may be parallel connected to the forward rotation command signal of the SPECIFIED inverter.						

### ⑦ Directions of Parameter **P6** [Logic condition Setting Relay "J1", "J2", "J3"]:

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

Setting	Explanation					Default Setting	Normal Value
	Higher Bits	Lower Bits					
00~17	0---Selecting 0~10V	Contact Status	<b>J3</b>	<b>J2</b>	<b>J1</b>	00 (Relay Dynamic Close output, analog output of 0~10V is effective)	
	1--- Selecting 10~0V	<b>0</b>	Dynamic Close	Dynamic Close	Dynamic Close		
	2--- Selecting -10~10V	<b>1</b>	Dynamic Close	Dynamic Close	Dynamic Open		
	3--- Selecting +10~-10V	<b>2</b>	Dynamic Close	Dynamic Open	Dynamic Close		
	4--- Selecting 0~+5V	<b>3</b>	Dynamic Close	Dynamic Open	Dynamic Open		
		<b>4</b>	Dynamic Open	Dynamic Close	Dynamic Close		
		<b>5</b>	Dynamic Open	Dynamic Close	Dynamic Open		
		<b>6</b>	Dynamic Open	Dynamic Open	Dynamic Close		
	<b>7</b>	Dynamic Open	Dynamic Open	Dynamic Open			

### ⑧ Directions of Parameter **P7** [Setting Relay“J1”Operation Range]:

Setting	Explanation		Default Setting	Normal Value
00~99 A0~A9 b0~b9 C0~C9 d0~d9 E0~E9 F0~F9	When Load $\geq$ Rated load $\times$ P7%, “J1”signal is output.		05 Setting J1: actuating for 05% Rated Load	
	<b>00~99</b> : Actuating for 0~99% rated load			
	<b>A0~A9</b> : Actuating for 100~109% rated load			
	<b>b0~b9</b> : Actuating for 110~119% rated load			
	<b>C0~C9</b> : Actuating for 120~129% rated load			
	<b>d0~d9</b> : Actuating for 130~139% rated load			
	<b>E0~E9</b> : Actuating for 140~149% rated load			
<b>F0~F9</b> : Actuating for 150~159% rated load				
Example	<b>P7=80</b> : For effective load of 1T, system actuates at 800Kg.			
	<b>P7=A5</b> : For effective load of 1T, system actuates at 1050Kg.			

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

		P7=C5: For effective load of 1T, system actuates at 1250Kg.	
--	--	---	--

### ⑨ Directions of Parameter P8 [Setting Relay“J2”Operation Range]:

Setting	Explanation	Default Setting	Normal Value
The same as P7	The same as P7: When load $\geq$ Rated Load $\times$ P8%, output “J2”signal	A0 Setting“J2”, system actuates at 90% rated load	

### ⑩ Directions of Parameter P9 [Setting Relay“J3”Operation Range]:

Setting	Explanation	Default Setting	Normal Value
The same as P7	The same as P7: When load $\geq$ Rated Load $\times$ P9%, output “J3”signal	A5 Setting“J3”, system actuates at 105% rated load	

### ⓐ Directions of Parameter PA [No-Load Auto Zeroing Time Interval]:

Setting	Explanation	Default Setting	Normal Value
00~96 (Hours)	When it reaches the set time, system will begin the operation of no load zeroing automatically. 01—— System disables the function of no load auto zeroing. 12~96—After system powered on (for 12~96 hours), it begins the operation of inspecting load detaining time, a part of no load zeroing operation.	00(Disable)	

### ⓑ Directions of Parameter PB [Detaining Time of No-Load Auto Zeroing]:

Setting	Explanation	Default Setting	Normal Value
10~90 (Minutes)	After auto zeroing time is reached, system load doesn't change in this period and system will allow the beginning of No-Load Auto Zeroing operation.	30(Minutes)	

### ⓒ Directions of Parameter PC [No load Auto Zeroing Error Range]:

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

Setting	Explanation	Default Setting	Normal Value
03~20 (%)	When conditions of both (7) and (8) being satisfied and the ratio of present load to the absolute value of original no load is larger than this setting, system begins No load Auto Zeroing operation immediately.	05% ([No load Error] larger than 5%, System)	

### 14 Directions of Parameter PD [Characteristics of Compensation Terminals]:

Setting	Explanation		Default Setting	Normal Value
00~03		PX.1~2	PX.3~4	00 PX.1~2、PX.3~4 Effective for High Voltage Level
	00	Effective for High Voltage Level	Effective for High Voltage Level	
	01	Effective for Low Voltage Level	Effective for High Voltage Level	
	02	Effective for High Voltage Level	Effective for Low Voltage Level	
	03	Effective for Low Voltage Level	Effective for Low Voltage Level	

### 15 Directions of Parameter PE [Selection of Sensor Parameters]:

Setting	Explanation				Default Setting	Normal Value
80~90	D7~D4	D3	D2	D1	0d	
		Sensor Gain Adjustment 0 ~ 3 gain-Levels for selection		D0		
Recommendation: Normally, users don't need to adjust this parameter. Any dissidence, contact with the manufacturer directly.						

- Attentions:
- ① When selecting not indicated settings, system will not normally operate.
  - ② No load auto zeroing parameters PA, PB and PC should be used cautiously because of the cause variety of elevator no load point drifting. It is recommended for the user to allow or forbid this function according to the concrete conditions.
  - ③ Even if No load auto zeroing operation is enabled, in the course of elevator periodical maintenance, autotuning operation of this system should be redone without exception.

## Explanation of Displaying Code:

### 10. System Normal Operation Code:

【J0】	【J1】	【J2】	【J3】
No Relay Output	RelayJ1 Output	RelayJ2 Output	RelayJ2 Output
	Default 5% of Rated Load	Default 90% of Rated Load	Default 105% of Rated Load
<p>1. Displaying “HJ※※※※”when pressing 【▲】 button indicates present car effective load. For instance, displaying“HJ0520 ”indicates the load of 0520kg.</p> <p>2. Displaying “.※. ※.” when pressing 【▼】 button or in the course of landing changing indicates present system compensating landing. Adjusting Personnel may judge whether system compensating landing tracing is right or not by its numerical value. Note: This option is just for floor-by floor compensation method.</p> <p>3. Displaying “0.0.”in fuzzy compensation indicates compensation is effective. Displaying “0.1.”indicates elevator entering modifying zone.</p>			

### 11. Code for Other Operation and Failures

	Display Code	Indication	Solution
1	FY	System Startup	
2	PC	Sensor Resetting	
3	PP	Get into the status of operation parameters modification	
4	PL	Autotuning No load parameters	(Still <b>Displaying</b> indicates preparation status, <b>aglimmer displaying</b> indicates the end of inspection)
5	PH	Autotuning Rated load parameters	
6	LL	Installation and positioning	Sensor having no load
7	LH		Too small Positioning
8	Lo		Sensor overload
9	LP		Accurately Position
			Interior Auto Correction

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

	Display Code	Indication	Solution
10	LY	Forcibly skip sensor interior auto correction	
11	P*	System Configuration Indication	
12	Pn	Saved	
13	EA	Saving Failure	Modifying operation parameters again
14	EJ	Without this system setting	Check system settings
15	EH	Applied Overflowing Pressure	Sensor pressure may beyond its withstanding range
16	EL	Applied Insufficient Pressure	Sensor being not pressed
17	EE	No landing of this code	Make certain PC signals abnormality or no load autotuning normal or not
18	EF	Memorizing abnormally	Repeat this operation.
19	ES	Communication Failure	Carefully check wiring between sensor and control.

## How to do?

### 12. Brief Analysis of Other Conditions:

(1) Bad system Operation Stability with the main indication of large output fluctuation in the condition of fixed load and elevator motionless?

*Check if PV power supply source fulfils system requirements?*

(2) After long-term of operation, system no load zeroing point appears larger deviation?

*Please set up the system self-learning mode to calibration, or startup parameter "PA≠0" to realize the function of system no load auto zeroing.*

(3) System displaying failure code  $[[EE]]$  ?

*Incorrect Input signal of terminal PX on the control or unreasonably setting.*

(4) When selecting floor indication step counting control method, floor-by-floor compensation consistency is bad?

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

---

*Whether up or down landing signals or leveling signal is normally wiring , Setting of parameter P5 is reasonable?*

(5)Traveling Up and down with the same load and stopping at the same floor, but the weighing result is different?

① *Lift rope pull is not symmetrical , adjust please.*

② *Elevator guide shoes are too tightened , running friction is large. It is recommended to adjust or modify relevant mechanical part to make it move flexible , then operate the system to autotune again.*

(6)System output signal doesn't change linearly along with load?

*Maybe system sensor is damaged.*

(7)How to descry present effective load of elevator car?

① *In the period of system normal operation, press button 【▲】. This moment, system displays [HJ] → [\*\*] → [\*\*] . For example : displaying [HJ]→[09]→[50] indicates a car with rated load of 1000 Kg presently bearing an effective load of 950Kg.*

② *If elevator effective load is not 1000 Kg , it may be decided after system autotuning operation is finished by modifying parameter“P1”.*

③ *Because of various impacts from outer environment , displayed data may fluctuate in a small scope.*

(8)When elevator is motionless, weighing signal is normal. But in the course of door opening, it is abnormal?

(9)During system operation, analog output is abnormal, repeatedly resetting or abnormal coordination with speed regulator?

*May be caused by crossing and interfering system power source. Select another set of power source to supply power to system , or equip AC/DC 24V/300mA exterior power source to supply power.*

### 13.How to Repeat doing Autotune operation for system?

**Method 1:** Simultaneously press 【▲】 and 【▼】 on system control panel to power on. This moment, system aglimmer displays [PP] and [P-]. Keep 10 seconds, system will display [Pn]. On that occasion, all operation parameters reset to default settings.

**Method 2:** Modifying parameter P0=0A will reset system immediately to default status. But for users with specified code, it is necessary to modify parameter P0 as appointed code. Detailed operation is described in chapter 8.

#### **14.How to adopt 20% rated load for rated load autotune?**

After system displaying  $[[Lo]]$ , modify parameter“P1=02”.Do no load autotuning operation as described in chapter 7. In the period of displaying  $[[PH]]$  , load elevator car with a weight equal to 20% of rated load to do rated load autotuning operation. When operation is finished,  $[[L1]]$  is displayed.

### **System Features**

#### **15.Main Characteristic:**

- (1) Selecting super thin “Disc” type intelligent load sensor , it is capable of directly inspecting elevator car load change unnecessary to change the pull rod of traction rope shackle;
- (2) Weighing range is wide (effective load of 500Kg ~ 5500 Kg) , high-accuracy position , intelligent temperature compensation.
- (3) Electric property complies with the requirements of “International Electro-technical Commission (IEC) ”Standard.
- (4) Inner core consists of highly accurate load sensor and high performance single-chip micro-computer. All operation parameters can be set on field.
- (5) Auto on-site measuring of various compensation methods, boosting requirement of high accuracy weighing signal of elevator system.
- (6) System may do scientific calculation according to mathematical equations with the function of no-load auto zeroing , automatically modifying measuring error.

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

- (7) Directly displaying present effective load. Some types may directly measure dead weight of elevator car for the benefit of users.
- (8) Field adjustment may select 20% or 100% rate load autotuning method or load setting method, being easily adjusted and operated.
- (9) Independent development of the method of **Programmable Output Signal Control** is suitable for all the requirement of traction elevators with various kinds of fixed car platform.
- (10) Having the function of operation parameters auto modification, auto accommodation to multi methods of intelligent floor compensation function, being applicable to traction elevators of less than 30 landings.
- (11) Distinctive design structure of sensor+ controller, only 2 connecting wires between sensor and controller making wiring simply.
- (12) The whole shoot starts from users' point of view, easy installation and adjustment, decreasing users' additional cost in use, high ratio of performance to price.

### 16. Technical Specifications:

1. Application	Being applicable to all traction elevators fixed car platform (less than 60 landings) with the load of 500 kg ~ 5000 kg .
2. Floor Compensation:	Auto accommodating to the following compensation methods: ①Up and Down leveling; ②Up command + door zone; ③Fuzzy and intelligent.
3. Sensitivity	Elevator Rated Capacity/200 (Example: The rated capacity is 1000 kg, and the sensitivity is 5 kg ) [This data may be affected by elevator mechanical performance.]
4. System Error	$\leq 0.5\%$ (5 ~ 40°C)
5. Non-Linearity	$\leq 0.5\%$
6. Compensation	The method of circuit parallel connection is applicable to the signal source system

## Technical File of EWD-RLG-SJ3 Serial Intelligent Elevator Weighing Device [User's Guide]

		of DC12~32V. Also, the interior fault of this system doesn't affect the original operation mode of elevator.
7.	Output Mode	Relay
		Programmable universal signal
		<p>① 3-channel programmable output modes are: No load, light load, semi full load, heavy load, rated load, and overload (customer may set the changing range freely).</p> <p>② Each channel can be programmed as dynamic <b>Close</b> or <b>Open</b> contact.</p> <p>③ Contact Capacity: DC/AC 48V/100mA</p>
		Analogue quantity
		Overall Compensation Range 0 ~ 10V, -10V ~ +10V, 0V ~ +5V
8.	Ambient Temperature	Temperature: -20 ~ 55 °C
9.	Relative Humidity	20% ~ 90% RH
10.	Reaction Time	≤ 0.5 Second. The communication distance between the intelligent and the control is 0~400m.
11.	Power Supply:	AC/DC24(±10%)V / 200mA
12.	Installation Place	Sensor Section: At the place of traction rope shackle
		Controller Section: Control Cabinet in machineroom. See the figure 3 for installing dimension.
13.	Overall Size:	Sensor Section: See the attached sheet; Controller Section: 115×90×40 mm <sup>3</sup>

: The intension exceeding the limit parameters listed above may result in the abnormality or permanent damage to the system.

## Promise

- (1) If this system appears any quality problem of product itself in 1 year after delivery, it will be replaced freely (damage of the product seal will not be dealt with) .
- (2) For any requirement of special functions, make it out by mail.
- (3) Any system abnormality in adjustment or operation, please contact our company directly.

**Others:**

<b>1.Packing List:</b>	XCL-Y/8625: Intelligent “Disc” type load sensor	1Set	XCL-ZL/W: Intelligent Character “王” tension sensor	1set
	Sensor Auxiliary Support	1Piece		
	<i>M10×35mm Fastening Screw sets</i>	6 sets		
	XCL-T/A: Intelligent Character “—”load sensor	1 set	EWD-RLG-SJ3 controller	1set
	<i>M10×35mm Fastening Screw sets</i>	2 sets	$\Phi 4\times 40\text{mm}$ <i>Fastening Screw sets</i>	4set s

**2.Address book: :**

Xi'AN EXCELLENT ELECTROMECHANICAL CO.,LTD



: (029)88416613, 18092639750  
18092639752




: 7D, Block A, Olympic Building, 14th Chang An North Road, Xi'an, Shaanxi,China

## Attached document:


### Load sensor dimensions and installation

#### 1. XCL-Y/8625 loading Sensor size and installation method


##### 1.1 size (range:1.2T、 2.2T、 3T 、 4T 、 5T 、 7T )



## Bar size chart





## 1.2 install method



## 2. XCL-ZL/W Standard character “王” tension sensor size and installation method



### 2.1 Size of load sensor

#### 2.1.1 The range is 2T size




Note: the installation must use  $\phi 6$  wire rope link safety ring and solid in the tractor nail to prevent the elevator installation and commissioning when the sensor off, to confirm personal safety.

### 2.1.2 The range is 5T size.



Note: the installation must use  $\phi 6$  wire rope link safety ring and solid in the tractor nail to prevent the elevator installation and commissioning when the sensor off, to confirm personal safety.


## 2.2 installation method




### 3.XCL-T/A Standard character “—” load sensor size and installation method

#### 3.1 load sensor size


##### 3.1.1 the rang is 1T、1.5T size




### 3.1.2 the rang is 3T、5T size




### 3.1.3 the rang is 7T、10T size



### 3.1.3 the rang is 15T size




## 3.2 installation method




## 4.XCL-T/B Standard character “—” load sensor size and installation method

### 4.1 load sensor size


#### 4.1.1 the rang is 3T、5T size



4.1.2 the rang is 7T、10T size



### 4.1.3 the rang is 15T size



## 4.2 installation method



## 5. XCL-ZL/P3 sensor size and installation method

5.1 the size is 0.5T for every one

5.2 installation method

